

Ground points

B = Located on left fender

D = Located on intake manifold

E = Located on left kick panel


IGNITION COIL AND IGNITER
IGNITER
DISTRIBUTOR
INJECTOR
NOISE FILTER
No. 1
No. 3
No. 2
No. 4
#10
#20
NE
IGF
IGT
T
VF
DG
OX
HT
E01
E02
E1
KNK
(4WD A/T)
CHECK CONNECTOR
OXYGEN SENSOR
KNOCK SENSOR
+B
FP
EI
IG-
-B
E
B
D
E